

# INSTALLATION INSTRUCTIONS

## FUEL BRAKE LINE RETAINER KIT

### BMW E36 E46



Document: 19-0363

Support: info@radiumauto.com

STEP	TOOLS NEEDED	INSTRUCTIONS	PHOTO
1	13mm Socket	Unscrew the 2 rearward fuel and brake line retainers.	
2		Pry all lines from the fuel and brake line retainers.	
3		For BMW E36, nothing shown will be reused.	
		NOTE: For the BMW E46, only the 2 plastic mounting nuts, shown in the picture, would be reused.	
4	Screwdriver	If removing the fuel feed and return lines from the vehicle, first get into the interior of the vehicle. The OEM feed line is clipped onto the top of fuel tank in the center (under the sheet metal). Reach your hands into the RH and LH access hole openings one at a time. Feel for the fuel feed line and pull upwards to release.	
5	3mm Allen Wrench	For the BMW E36, press the included stainless steel bushings into the aluminum retainers. Route the fuel lines along the OEM brake hard lines. Secure the retainers with the 2 provided stainless steel screws.	
	13mm Socket		
		NOTE: For BMW E46, the OEM plastic nuts would be used with the aluminum retainers instead of the bushings and screws shown.	