



INSTALLATION INSTRUCTIONS

8AN ORB TO SCHRADER VALVE

Document: 19-0391

Support: info@radiumauto.com

CAUTION

Only a qualified technician following applicable safety procedures should perform the installation of this product. One must have knowledge in repair and modification of fuel systems and general vehicle modifications to install this product.

Gasoline and other fuels are flammable and can be explosive.

Only install in a well-ventilated location to minimize buildup of fuel vapors.

Proper eye and personal protection is required at all times during installation.

Proper eye and personal protection is required at all times during installation.

WARNING

The fuel system is under pressure! Do not loosen any connections until relieving the fuel system pressure.

Consult a service manual for instructions on relieving fuel pressure safely. This product is designed for off-highway and racing use only.

Fuel system components may not be legal for sale or use on emissions controlled motor vehicles. Consult local, state, and federal laws.

STEP	TOOLS NEEDED	INSTRUCTIONS	PHOTO
1	PTFE Thread Paste	Apply PTFE thread paste to the Schrader valve threads.	
2	Vice 7/8" Wrench	Hand tighten the Schrader valve to the 8AN ORB fitting. Now add 1.5 to 3 turns with a wrench.	
3	Oil Lubrication	Lubricate the 8AN ORB O-ring.	
4	7/8" Wrench	Secure the Schrader valve assembly to an 8AN ORB port.	