



# INSTALLATION INSTRUCTIONS

## PUMP CLAMP FOR 41-43MM BODIES

Document: 19-0398

Support: info@radiumauto.com

### CAUTION

Only a qualified technician following applicable safety procedures should perform the installation of this product. One must have knowledge in repair and modification of fuel systems and general vehicle modifications to install this product.



**Gasoline and other fuels are flammable and can be explosive.**

Only install in a well-ventilated location to minimize buildup of fuel vapors.

No sparks, open flames, smoking or other ignition sources are to be present. Draining and removal of all fuel from the fuel system is recommended. Proper eye and personal protection is required at all times during installation.

### WARNING

The fuel system is under pressure! Do not loosen any connections until relieving the fuel system pressure. Consult a service manual for instructions on relieving fuel pressure safely. This product is designed for off-highway and racing use only. Fuel system components may not be legal for sale or use on emissions controlled motor vehicles. Consult local, state, and federal laws.

| STEP | TOOLS NEEDED       | INSTRUCTIONS                                                                                                     | PHOTO                                                                                 |
|------|--------------------|------------------------------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------|
| 1    |                    | To check fuel pump brand/model compatibility, go to <a href="http://www.radiumauto.com">www.radiumauto.com</a> . |   |
|      |                    |                                                                                                                  |                                                                                       |
|      |                    |                                                                                                                  |                                                                                       |
|      |                    |                                                                                                                  |                                                                                       |
|      |                    |                                                                                                                  |                                                                                       |
| 2    |                    | Roll the provided FKM O-ring over the fuel pump body.                                                            |  |
|      |                    |                                                                                                                  |                                                                                       |
|      |                    |                                                                                                                  |                                                                                       |
|      |                    |                                                                                                                  |                                                                                       |
|      |                    |                                                                                                                  |                                                                                       |
| 3    | 3mm Allen Wrench   | Secure the 2 clamps halves together, as shown.                                                                   |  |
|      |                    |                                                                                                                  |                                                                                       |
|      |                    |                                                                                                                  |                                                                                       |
|      |                    |                                                                                                                  |                                                                                       |
|      |                    |                                                                                                                  |                                                                                       |
| 4    | 2.5mm Allen Wrench | The button head screws are used as shown.                                                                        |  |
|      |                    |                                                                                                                  |                                                                                       |
|      |                    |                                                                                                                  |                                                                                       |
|      |                    |                                                                                                                  |                                                                                       |
|      |                    |                                                                                                                  |                                                                                       |