



INSTALLATION INSTRUCTIONS

FUEL BRAKE LINE RETAINER KIT

2016+ HONDA CIVIC

Document: 19-0375

Support: info@radiumauto.com

CAUTION

Only a qualified technician following applicable safety procedures should perform the installation of this product. One must have knowledge in repair and modification of fuel systems and general vehicle modifications to install this product.

Gasoline and other fuels are flammable and can be explosive.

Only install in a well-ventilated location to minimize buildup of fuel vapors.

Only install in a well ventilated location to minimize buildup of fuel vapors.
No sparks, open flames, smoking or other ignition sources are to be present. Draining and removal of all fuel from the fuel system is recommended.
Proper eye and personal protection is required at all times during installation.

Proper eye and personal protection is required at all times during installation.

WARNING

The fuel system is under pressure! Do not loosen any connections until relieving the fuel system pressure.

Consult a service manual for instructions on relieving fuel pressure safely. This product is designed for off-highway and racing use only.

Fuel system components may not be legal for sale or use on emissions controlled motor vehicles. Consult local, state, and federal laws.

STEP	TOOLS NEEDED	INSTRUCTIONS	PHOTO
1		<p>There are 3 plastic fuel/brake line retainers underneath the center portion of the car. These will be replaced.</p> <p>First, gently pull the heat shield down to expose the lines. Next, spread the locks away from the threaded studs.</p>	
2		Next, pry the plastic fuel/brake line retainers downward away from the chassis.	
3		One of the plastic fuel/brake line retainers is shown.	
4	11mm Socket	The replacement retainers are 2 piece. As shown, install the black upper portions using the included plastic flanged nuts.	

5	2.5mm Allen Wrench	<p>Find the 3 lower (green) retainers and the 6 small M3x0.5mm screws in the kit. Insert the hose (not included).</p> <p>Starting from the center retainer, secure the hose, as shown.</p>	
6	2.5mm Allen Wrench	<p>Now secure the hose using the front and rear retainers, as shown.</p>	